

# LazyBone Dimmer WiFi Configuration Guide



Tinysine Electronics @ 2016 Version 1.0



#### Step 1: Connect to AP network

LazyBone dimmer has a configuration switch, please set the switch to **AP** position then power the dimmer, it will create an AP network.



Next, turn on your phone's WiFi to find a network named as **WiFly-EZX-XX**, it's an open network that does not need a pass phrase or pass key. **XX** stands for the last two characters of WiFi module's MAC address.



### Step 2: Control dimmer point to point in AP mode

When your phone has connected to AP network, you can control the dimmer point to point. Just download the Android/iOS on our website: <a href="http://www.tinyosshop.com">www.tinyosshop.com</a>

Andorid APP: www.tinyosshop.com/datasheet/LazyBoneDimmer-WIFI.apk

iOS APP: <u>https://itunes.apple.com/hk/app/lazybone-dm/id660708517?mt=8</u> Or you can search **Lazybone dimmer WIFI** on apple store.

Please install the APP to your phone. Open the dimmer app, click "Connect device" and input IP as **192.168.1.1**, port is **2000**. When you see the words "connected: xxx", you can control dimmer now!



## Step 3: Configure dimmer's wifi

There are two methods to configure your LazyBone, **the first method is to use WiFiBee AP mode config tool.** 

http://www.tinyosshop.com/download/TinySine%20WiFibee%20config%20tool.rar

You can use it to set your wifibee/wifly in AP mode easily!

(1) Disconnect your phone from the AP network, connect your computer to this AP network.

(2) Input 192.168.1.1 in "Temporary Config".

(3) Input your WiFi SSID, password, then assign an proper IP address for your LazyBone.(4) Click "Start Configuration", wait for few minutes until you can see the words

"Configuration stopped", it means you have finished the configuration, so easy!

Temporary Config	192 , 168 , 1 , 1								
	Your WIEI SSTD:	TINYSI	NE30	11					1
	1001 1011 100101	0.000110.000	112.55						
	Your WiFi Password:	000000	0000	0					
	Assign a valid IP to WiFi Unit:	192		168	£	3		185	
	DHCP:	OFF	8	•					
	Silent Mode:	ON	2	•					
	IDLE Time (s):	20							
ſ	Start Configuratio	n	_		_	_	_	_	n'
		S14						_	U 1
	10	0.14:						_	
Leceived: set sys printly	10							_	
Received: set sys printly Received:	10								
Leceived: set sys printlv Received: AOK	10							_	
Received: set sys printly Received: AOK <4.41>	10								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20	10								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41>	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received: save	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received:	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received: save	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received: sove Received: Storing in config <4.41>	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received: save Received: Storing in config <4.41> Sent: reboot	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received: save Received: Storing in config <4.41> Sent: reboot Received: reboot	20								
Received: set sys printlv Received: AOK <4.41> Sent: set comm idle 20 Received: set comm idle AOK <4.41> Sent: save Received: save Received: save Received: save Received: set config <4.41> Sent: reboot Received: reboot Received: reboot	20								

Note1: Our WIFI SSID is TINYSINE301, Password is 000000000. Here you need replace them with your home WIFI SSID and password.

Note2: Our WIFI router IP address is 192.168.3.1. So we assigned a valid IP 192.168.3.185 to the WIFIBee Module. You need change it to your IP address.

When the configuration has finished. Disconnect LazyBone from its power, change the configuration switch back to the **Normal** position, and re-power LazyBone again. Then skip to STEP4.

#### The second method is to use Hyper Terminal in Windows.

(1) Set your computer to obtain IP address automatically and open the network list. You should see a wireless network named **Wifly-EZX-XX**, click it to connect.





**NOTE:** It may take a while for Windows to connect to the network and assign an IP address. You can check the IP address of your computer by running the ipconfig command in the command window. Once connected, this command will show you the IP address and net mask.

The IP address assigned by Auto IP must be on the subnet 192.168.1.x, otherwise the LazyBone WiFi module will not be accessible.

meral	Support	
Connec	Address Type:	Assigned by DHCP
	Subnet Mask:	255.255.255.0
Window	Default Gateway: Details s did not detect problems with 1	192.168.1.1
Repair.		n, -

If your computer has both wireless and wired interface hardware, please disable the wired LAN interface hardware before connecting to the AP network, or the computer may assign an IP address that is not on the same subnet as the WiFi module.

(2) Run Hyper Terminal and create a new connection.

Set Host address to **192.168.1.1**, Port number is **2000**.

🌯 wifi - HyperTermin	al	×
File Edit View Call Tr	ansfer Help	
		~
	Connect To	
	wili Enter details for the host that you want to call:	
	Host address: 192.168.1.1	
	Port number: 2000	
	Connect using: TCP/IP (Winsock)	
	OK Cancel	
<		<u>×</u>
Disconnected	Auto detect Auto detect SCROLL CAPS NUM Captur	e Print echo ,;

(3) Once connected with a proper IP address, you should see the response **\*HELLO\***. Input escape sequence **\$\$\$** to make the WiFi module enter commands mode, and Hyper



Terminal should return **CMD** to you.

🍓 wifi - HyperTermi	inal				
File Edit View Call	Transfer Help				
0 🌶 🍘 🍒 🗈	8				
					^
*HELLO*CMD					
					- 11
					Ξ.
					50
					_
					~
<					>
Connected 0:00:16	Auto detect	TCP/IP	SCROLL CAPS	NUM Capture	Print echo

(4) Now you can setup the WiFi module's settings. Input every command on your keyboard, and click the **Enter** button after each command to send. The Hyper Terminal should return **AOK**.

set wlan phrase <your WPA password> set wlan ssid <your network ssid> set wlan join 1 save

🏶 wifi - HyperTermi	nal						
File Edit View Call T	ransfer Help						
06 88 10	86						
							_^
*HELLO*CMD set wlan phr	rase 000	0000000					
<4.00> set u AOK	wlan ssi	d Tiny\$	ine3f				
<4.00> set u AOK	wlan joi	n 1					
<4.00> save Storing in a <4.00> reboo	config ot						
							~
Support of the second secon	Auto detect	TCP/IP	SCROLL	CAPS	NUM	Capture	Prin

If you want a fixed IP address, please use these commands below: set ip a <your IP address> set ip dhcp 0 set sys printlvl 0 save reboot



Here we set IP address to 192.168.3.185 for demo purposes.

(5) When the configuration has finished, close Hyper Terminal, disconnect LazyBone from its power, change the configuration switch back to the **Normal** position, and re-power LazyBone again.





### Step 4: Connect LazyBone to Android phone/iPhone

(1) Open the dimmer app, input the configuration information as we set before. You can name for LazyBone dimmer in the first line, the second line is IP address, in our case we write 192.168.3.185, and the third is the port which we set to **2000**. then click **ok**.



(2) When you see the words "**Connected: xxx**", it means your phone has connected to LazyBone successfully, now you can use LazyBone to dim your bulb!





# **Contact us**

Address: Tinysine (Tinyos) Electronics 4-3 Hui Gu Park, Hai Tang Road, Hefei, Anhui, China **Telephone:** +86-551-65365921 Ext 801

Working Time: 9:00-17:30 (GTM +8)

**Fax:** +86-551-65365931



Email: <a href="mailto:customerservice@tinyosshop.com">customerservice@tinyosshop.com</a>